

# Integration of the Easee AC charging station into the Eponet portal

These instructions are step 3 for connecting an Easee charging station to the Eponet portal.

Step 1 can be found at this link: [Basic instructions for integrating charging stations](#)

grafik.png

Software versions for Easee charging stations. The software is automatically updated by Easee via the cloud.

The Easee can now also be controlled directly via OCPP in load management. This means that a separate account is no longer required for each installation.

PIN - A PIN is included with the charging station. You will need this for connection and configuration.

Tip: Save this PIN in the Eponet portal for each charging station. The PIN is also required for future support.

## Preparing the charging station via Easee Cloud

The Easee charging station is configured via the Easee Cloud. Log in to the Easee Cloud, select the desired location and configure the Easee Cloud according to the manufacturer's instructions.

Once the Easee system has been configured, you can easily switch the location to Eponet via Tools > Technical Operator:

grafik.png

Remove the previous operator and select Eponet:

grafik.png

From this point on, the location is connected to the Eponet OCPP server (all charging stations in this installation are connected to Eponet).

## Important

Make a note of, or even better, copy the serial number of your Easee charging station (e.g. EC102xxx). You will need this serial number later in the Eponet portal. You can easily copy it under Products.

We recommend the following configuration (must be set for each charging station in the Easee Cloud). Please note that Eponet is not responsible if the charging station is configured incorrectly and, for example, offline charging is permitted, resulting in incorrect billing in the Eponet portal:

grafik.png

Please ensure that the configuration is set correctly as shown above. Please note that Eponet is not responsible if the charging station is configured incorrectly and, for example, offline charging is permitted, resulting in incorrect billing in the Eponet portal.

From this point on, the installation is connected to the Eponet OCPP server (all charging stations in this installation are connected to Eponet).

### Checklist:

- Authentication required > **must be activated**
- Deactivate authorisation when the charging stations are offline > **must not be activated**
- Is the charging station online on the Eponet portal?

Now continue with step 4.

---

Revision #9

Created 17 January 2025 10:06:37 by David Brouwer

Updated 9 April 2025 09:13:29