

Adding an Eponet RFID reader to a charging station

Once the EdgeServer and the required USR Device Server are installed on site, you can register the corresponding Eponet RFID readers as follows.

First, follow arrows 1 and 2.

Bildschirmfoto 2025-06-04 um 09.58.33.png

Now select the corresponding charging station and click on "Config" at arrow 3.

Bildschirmfoto 2025-06-04 um 09.58.44.png

Now enter the Mac address of the EdgeServer for RFID management under "Edge MAC".

Bildschirmfoto 2025-06-04 um 09.59.09.png

Now click on "Add" and enter the number that is manually written on the reader in "Device ID". Confirm this by clicking on "Add".

Bildschirmfoto 2025-06-04 um 09.59.25.png

It should then look as shown below and you can complete the configuration for this charging station by clicking on the "Save" button.

Bildschirmfoto 2025-06-04 um 09.59.44.png

A reader can only be used for one charging station and not for several!

Revision #4

Created 4 June 2025 08:50:54 by David Brouwer

Updated 4 June 2025 08:55:33 by David Brouwer